




SAFETY FOOTWEAR

6



LEGISLATION

Whilst EN ISO 20345 is the current standard to which new or routinely re-tested footwear has to conform it is still acceptable for existing styles tested and approved to EN345 to be sold. The standard to which the footwear conforms will be identified on the product information label within the footwear.

Both versions of the standard require the inclusion of a 200 joule toe cap for impact protection. In addition to the over arching requirements of the standards there are a number of progressive ratings which assist selection of footwear appropriate for varying workplace hazards, these are:

- SB – safety basic footwear meeting all the minimum requirements of the standard
- S1 – additionally featuring anti-static properties and fully enclosed and energy absorbing heel unit
- S2 – additionally featuring the use of water resistant leather
- S3 – additionally featuring cleated outsole and pierce resistant midsole
- S4 – Rubber or polymeric waterproof footwear with 200 joule toecap, anti-static properties and energy absorbing heel unit.
- S5 – additionally featuring cleated outsole and pierce resistant midsole

Additional protective features can be built into the footwear and are identified by the following suffixes:

- P – protection from upward penetration provided by a composite or steel midsole (not used in conjunction with S3 or S5)
- C – conductive properties helping to prevent the build-up of static (but no protection against electric shock)
- A – anti-static properties to prevent the build-up of static and give limited protection against electric shock
- HI – insulation against heat
- CI – insulation against cold
- E – energy absorption in heel unit
- WRU – water resistant uppers
- HRO – resistance to hot contact up to 300°C

 Denotes footwear with safety toecap	 Denotes footwear suitable for women
 Denotes footwear with safety midsole	 Denotes footwear with anti-static soles
 Denotes water repellent footwear	 Denotes waterproof footwear

SLIP RESISTANCE

Slips trips and falls are ever present hazards in most workplaces and safety footwear can play it's part in preventing injury particularly from slips by featuring slip resistant soles units.

For many years the test of choice for slip resistance has been SATRA's TM144 standard which evaluates the performance of the sole unit on a water wet quarry tile. Well established styles of footwear are likely to have been tested to TM144 and will be identified as such by the TM144 icon.

However with regard to new styles of footwear undergoing periodic re-testing the recently established EN ISO 13287 with it's progressive SRA, SRB and SRC ratings has become more widely used.

Details of the EN ISO 13287 testing requirements are shown in the table below:

Slip resistance ratings for industrial PPE footwear in Europe			
Marking symbols and specifications			
Marking	Footwear slip resistant on	Minimum coefficient of friction by ISO 13287:2006	
		Forward heel slip	Forward flat slip
SRA	Ceramic tile with 0.5% SLS solution	0.28	0.32
SRB	Steel with 90% glycerine	0.13	0.18
SRC	Both the above	Both the above on respective surfaces	Both the above on respective surfaces

NB: ISO 13287:2006 is identical to EN ISO 13287:2007

Footwear tested to EN ISO 13287 and the rating achieved will be identified by the appropriate SRA/SRB/SRC icon.

 Denotes TM144 rating	 Denotes SRA rating
 Denotes SRB rating	 Denotes SRC rating

SIZING

Safety footwear often carries European sizing, please see below a comparison table.

SHOE SIZE CONVERSION TABLE												
This table is for guidance only as sizes are not standardised												
British	2	3	4	5	6	7	8	9	10	11	12	13
Continental	35	36	37	38	39	41	42	43	44	46	47	48

MAINTENANCE

As with all footwear it is essential that, to achieve optimum performance of the properties built in to the safety footwear at time of manufacture, safety footwear is cleaned and maintained regularly.

Choose the right footwear

Most workplaces have varying requirements for the provision of safety footwear which is why we offer a comprehensive range within which you should be able to identify appropriate footwear to meet the needs of your workforce whatever the hazards identified in your risk assessment.

Whilst protection is paramount it is recognised that with long wear periods, often in hostile conditions, wearer acceptance, design, brand and comfort are additional considerations. We therefore offer varying styles from executive shoes to heavy duty rigger boots, and leading brands such as CAT, Timberland, Dr Martens, RockFall, Jallatte, Lotus & Dunlop alongside our increasingly popular and cost effective Tuf Revolution, SoleMate & SoleStep ranges.



Protective footwear must be worn